



RWT420/440 Series Transducer Communication Protocol

**Revision 5 - October 2014
RWT320/340 MKII (Firmware Revision: 3)
RWT420/440 MKIII (Firmware Revision: 4)**

Table of Contents

Introduction	4
RS232 Settings	4
Protocol Description	4
Binary Format.....	4
ASCII Format.....	6
Torque Modes	7
Peak Torque.....	7
Peak Torque with AutoReset	7
Peak Torque CW.....	7
Peak Torque CCW	7
PeakMinMax	7
Speed Modes	8
Slow	8
Fast.....	8
Temperature Sensors	9
Ambient.....	9
Shaft.....	9
Internal	9
Unit Key	9
Command Set	10
Get Transducer ID.....	11
Get Transducer Information.....	12
Get Torque	13
Get Peak Torque	13
Get Peak Torque Auto Reset.....	13
Get Peak Torque CW	14
Get Peak Torque CCW.....	14
Get PeakMinMax Max	14
Get PeakMinMax Min	15
Get PeakMinMax.....	15
Get Torque - Convert Units To	15
Get Peak Torque - Convert Units To	16
Get Peak Torque Auto Reset - Convert Units To.....	16
Get Peak Torque CW - Convert Units To.....	17
Get Peak Torque CCW - Convert Units To.....	17
Get PeakMinMax Max - Convert Units To.....	18
Get PeakMinMax Min - Convert Units To.....	18
Get PeakMinMax - Convert Units To	19
Get Speed.....	19
Get Power	20
Get Temperature Ambient	20
Get Temperature Shaft.....	20
Get SlowCap Speed.....	21
Get FastCap Speed.....	21
Get SlowCap Power in Watts	21
Get FastCap Power in Watts	22
Get SlowCap Power in HP.....	22
Get FastCap Power in HP	22
Reset Specified Peaks	23
Reset ALL Peak Torque Values	25
Reset ALL Peak Values.....	25
Reset System Values	25
Peak Torque Reset	26
Peak Torque Auto Reset - Reset.....	26

Zero Transducer with Average	26
Zero Transducer.....	26
Get PeakMinMax & Reset	27
Set Torque Filter.....	27
Get Torque Filter	28
Set Speed Filter.....	28
Get Speed Filter	28

Contact Details

Sensor Technology Ltd,
Apollo Park,
Ironstone Lane,
Wroxton,
BANBURY,
OX15 6AY,
United Kingdom.

Sales

Email: stlsales@sensors.co.uk
Tel: +44 (0)1869 238400
Fax: +44 (0)1869 238401

Technical Support

Email: software@sensors.co.uk
Tel: +44 (0)1295 730746
Fax: +44 (0)1295 738966

Introduction

The RS232 and USB interfaces on the RWT300/400 Series Transducers provide a method of extracting digital operational data from the Transducer. Functions for controlling aspects of the Transducers operation are also present.

The protocol used is the same for both RS232 and USB, but due to USB’s more complex nature, it is recommended that the STCOMMDLL DLL be used to interface your own application to the Transducer. Further assistance can be provided if USB is needed on an unsupported platform, or the developer wishes to interface directly without the DLL.

RS232 Settings

The RS232 interface provides a full-duplex communication channel; each byte of data is transmitted in a packet of 10bits. The data packet consists of one start bit, 8 data bits, no parity and one stop bit.

Data Packet Format (D0 – Least Significant Bit)

Start Bit	D0	D1	D2	D3	D4	D5	D6	D7	Stop Bit
-----------	----	----	----	----	----	----	----	----	----------

The RS232 interface can operate at 3 different baud rates, 9600, 38400 and 115200bps (default). The baud rate can be changed by using the “Transducer Control” program which accompanies our RWT300/400 Series Transducers.

Protocol Description

The Transducer uses a simple request and send protocol. Data is transferred using either a binary or ASCII (Firmware v4.2) format. Firmware version 4.2 introduced a ASCII format alongside the original and efficient binary format. The ASCII format was added to provide compatibility with machines that had trouble decoding the binary data.

Binary Format

The binary format is a fast and efficient method of extracting data from the transducer. It has a much lower overhead compared to the ASCII format. Commands are one byte in length and either request data or switch Transducer functions on or off.

To request data, transmit a byte equal to the command number of the function you want to request, the Transducer will then reply with the relevant data or action your request. Some commands require additional parameters, in these cases the parameter data should follow the request byte, refer to the command descriptions for more information.

The data returned from request commands will be output in various formats, the format used depends upon the type of data requested. Multi-byte number types are output with the least significant byte (LSB) first, as with Little-Endian systems.

The data types used are C type variables, Int type variables are 2 bytes in size.

The following outlines the variable types used.

Float Data Type (4 bytes): IEEE-754 standard floating point number format.

Floating-point format:

SEEE EEEE EMMM MMMM MMMM MMMM MMMM MMMM
 S – Sign Bit, E – Exponent, M – Mantissa.

LSB Byte 0	Byte 1	Byte 2	MSB Byte 3
----------------------	--------	--------	----------------------

Unsigned Long Data Type (4 bytes): Long type unsigned integer.

LSB Byte 0	Byte 1	Byte 2	MSB Byte 3
----------------------	--------	--------	----------------------

Unsigned Int Data Type (2 bytes): Unsigned integer variable.

LSB Byte 0	MSB Byte 1
----------------------	----------------------

Unsigned Char (1 byte): Single byte unsigned integer variable.

Strings: C has no string variable as such; strings output from the Transducer are in the format of an array of Char type (1 byte) integer values terminated with a NULL character.

PeakMinMax: A structure containing two Float data types

Torque Peak Max			
LSB Byte 0	Byte 1	Byte 2	MSB Byte 3
Torque Peak Min			
LSB Byte 4	Byte 5	Byte 6	MSB Byte 7

Torque Modes

The primary purpose of the RWT Series Transducers is to measure Torque, the Torque value that is output from the Transducer is run through several processes within the firmware, these processes include a filter (if enabled), frequency to Torque rescaling, temperature correction and zero offset adjustment. The filter is a running average with a standard deviation cut off to remove spurious readings, the running average enables the sample throughput to be unaffected by filter size.

Once the final Torque value is computed it is run through a peak Torque capture algorithm. The peak Torque algorithm monitors the incoming data and compares it against a set of stored values using various criteria. If the value matches the criteria, that value replaces the stored value. In most cases the criterion is related to whether the captured value is greater than the stored value.

Peak values assume a reset position on start-up, when peak values are reset they are set to zero, PeakMinMax values are set to the current Torque value.

The peak Torque algorithm is run on every valid Torque reading captured, ensuring that no peak value is missed.

The Torque value unless specified will always be scaled in the native unit of measurement for the Transducer.

The following subsections describe the different types of peak Torque.

Peak Torque

The peak Torque value indicates the highest Torque applied to the transducer in either direction. The value is signed to indicate the direction that the Torque was applied in.

Peak Torque with AutoReset

The peak Torque with auto reset value is similar to the Peak Torque feature, it works in the same way by recording the maximum Torque, but automatically resets to zero when the current Torque value drops below a configured percentage of the peak value. When the reset triggers the peak is held for a few seconds before it is zeroed.

The default auto reset percentage is 80%; the percentage can be configured using the "Transducer Control" program which accompanies our RWT300/400 Series Transducers.

Peak Torque CW

The peak Torque CW value records the highest Torque value measured in the clockwise direction.

Peak Torque CCW

The peak torque CCW value records the highest Torque value measured in the counter-clockwise direction.

PeakMinMax

The PeakMinMax feature monitors the captured Torque values and records the lowest and highest value from a reference position. This reference is given via a reset command and assumes zero on power on. An example of the PeakMinMax feature is as follows: if the reference is set to 10, then the torque value goes up by 10 and down by 12, Max would be 20 and Min would be -2.

Speed Modes

Speed is decoded from a square wave signal, produced by a shaft mounted grating passing through an optical sensor. The frequency of the square wave indicates the rotational speed of the shaft. The transducer uses two methods for the measurement of Speed, both methods run simultaneously, offer good accuracy, but differ in measurement time. Speed is always measured in revolutions per minute (RPM).

Slow

The slow method uses a frequency count. Rising edges of the square wave are counted over a period of a second, after each second the count is converted into RPM. As the name suggests this method is slow, measurements will be produced at a rate of 1 a second. This method is good if you have a fluctuating drive speed and wish to filter the captured speed value.

Fast

The fast method uses a period count. The period count measures the time between rising edges of the square wave, then computes the RPM by turning the time into frequency. The fast methods measurement rate is variable and is directly related to the rotational speed of the transducer. When the rotational speed of the shaft rises above 2000 RPM the fast method will increase the number of rising edges over which time is measured, this is done to preserve measurement accuracy.

The fast methods measurement rate can be calculated from the following tables. The measurement rate differs between the RWT300 series and RWT400 series because of different implementations. The calculations shown are based on a standard 60 line grating.

RWT320/340 (MKII)

Rotational Speed (RPM)		Update Rate (Hz)
From	To	
0		1 Hz
1	2000	RPM / 2
2000	4000	$((\text{RPM} - 2000) \times 0.3227) + 650$
4000	8000	$((\text{RPM} - 4000) \times 0.196) + 800$
8000	16000	$((\text{RPM} - 8000) \times 0.1117) + 850$
16000	32000	$((\text{RPM} - 16000) \times 0.058) + 900$

RWT420/440 (MKIII)

Rotational Speed (RPM)	Update Rate (Hz)
0	1 Hz
< 2000	RPM
> 2000	$\text{RPM} \times (1 / (\lfloor (\text{RPM} - 1) / 2000 \rfloor + 1))$

Temperature Sensors

The Transducer monitors Temperature from three different sensors, these are defined as ambient, shaft and internal. The shaft Temperature is the only one which is used for compensation; the other two are for monitoring only. The Transducer measures Temperature in degrees Celsius.

Ambient

The ambient sensor is mounted in free air, stood off from the PCB it is mounted to.

Shaft

The shaft sensor is an infra-red device which is pointed directly at the centre of the shaft.

Internal

The internal sensor is part of the communications processor on the main processing board.

Unit Key

Some of the commands use a number to represent Transducer units or to indicate which units to convert to. The table below shows which number represents each unit, e.g. 7 = N.m.

0	ozf.in
1	lbf.in
2	lbf.ft
3	gf.cm
4	Kgf.cm
5	Kgf.m
6	mN.m
7	N.m

Command Set

The table below outlines the commands available:

Command	Function	Parameters	Return Value
<i>Transducer Identification</i>			
0	Get Transducer ID	None	Transducer ID String
1	Get Transducer Information	None	Transducer Information
<i>Transducer Data</i>			
50	Get Torque	None	Torque
51	Get Peak Torque	None	Peak Torque
52	Get Peak Torque Auto Reset	None	Peak Torque Auto Reset
53	Get Peak Torque CW	None	Peak Torque CW
54	Get Peak Torque CCW	None	Peak Torque CCW
55	Get PeakMinMax Max	None	PeakMinMax Max
56	Get PeakMinMax Min	None	PeakMinMax Min
57	Get PeakMinMax	None	PeakMinMax
60	Get Torque Convert Unit To	Units	Torque
61	Get Peak Torque Convert Units To	Units	Peak Torque
62	Get Peak Torque Auto Reset Convert Units To	Units	Peak Torque Auto Reset
63	Get Peak Torque CW Convert Units To	Units	Peak Torque CW
64	Get Peak Torque CCW Convert Units To	Units	Peak Torque CCW
65	Get PeakMinMax Max Convert Units To	Units	PeakMinMax Max
66	Get PeakMinMax Min Convert Units To	Units	PeakMinMax Min
67	Get PeakMinMax Convert Units To	Units	PeakMinMax
100	Get Speed	None	Speed
101	Get Power	None	Power in Watts
102	Get Temperature Ambient	None	Temperature Ambient
103	Get Temperature Shaft	None	Temperature Shaft
110	Get SlowCap Speed	None	Speed
111	Get FastCap Speed	None	Speed
112	Get SlowCap Power in Watts	None	Power in Watts
113	Get FastCap Power in Watts	None	Power in Watts
114	Get SlowCap Power in HP	None	Power in HP
115	Get FastCap Power in HP	None	Power in HP
<i>Transducer Control</i>			
146	Reset specified Peaks	See Description.	
147	Reset all Peak Torque values	None	None
148	Reset all Peaks	None	None
149	Reset System Values	None	None
150	Peak Torque Reset	None	None
152	Peak Torque Auto Reset - Reset	None	None

155	Zero Transducer with Average	None	None
156	Zero Transducer	None	None
173	PeakMinMax Retrieve & Reset	None	PeakMinMax
180	Set Torque filter	Filter Setting	None
181	Get Torque filter	None	Filter Setting
182	Set Speed filter	Filter Setting	None
183	Get Speed filter	None	Filter Setting

Transducer Identification

Get Transducer ID

	Binary	ASCII
Command	0	#0;
Description	<p>Requests an ID string from the Transducer. The ID string contains the Transducer Model Name, Firmware Revision and Serial Number.</p> <p>The ID string has the following format:</p> <p style="text-align: center;">RWT321-DA - Firmware Revision: 2.1 Serial Number: 12345678</p>	
Parameters	None	
Return Value	Transducer ID String	
	Char [58]	#ID STRING;

Get Transducer Information

	Binary	ASCII																
Command	1	#1;																
Description	Requests information on the Transducers configuration. The information details the Transducers setup.																	
Parameters	None																	
Return Value	<p>The transducer returns a structure of values, either as a packed C structure for binary or a delimited list in ASCII. The returned data contains the following fields, dates have the following format, DD/MM/YYYY.</p> <p>Model Name - Transducer Model Name. Type - Transducer Technology, reserved for future use. FSD - Transducer Full Scale. Units - Transducer Torque Unit, (In binary mode see Unit Key). Maximum Speed - Maximum tested/rated speed. Serial Number - Transducer Serial Number. Manufacture Date - Transducer Manufacture Date. Calibration Date - Transducer Calibration Date. Options - Enabled features.</p> <p>The options value is a combination of binary flags, the table below shows its makeup. Bit=1 Enabled, Bit=0 Disabled</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Bit0 (L)</th> <th>Bit1</th> <th>Bit2</th> <th>Bit3</th> </tr> </thead> <tbody> <tr> <td>USB</td> <td>RS232</td> <td>Advanced User Control</td> <td>Current Output</td> </tr> <tr> <th>Bit4</th> <th>Bit5</th> <th>Bit6</th> <th>Bit7 (M)</th> </tr> <tr> <td>None</td> <td>Speed Encoder</td> <td>Angle Encoder</td> <td>IP65</td> </tr> </tbody> </table>		Bit0 (L)	Bit1	Bit2	Bit3	USB	RS232	Advanced User Control	Current Output	Bit4	Bit5	Bit6	Bit7 (M)	None	Speed Encoder	Angle Encoder	IP65
	Bit0 (L)	Bit1	Bit2	Bit3														
USB	RS232	Advanced User Control	Current Output															
Bit4	Bit5	Bit6	Bit7 (M)															
None	Speed Encoder	Angle Encoder	IP65															
	<pre>Struct { char Model_Name[10]; unsigned char Type; unsigned int FSD; unsigned char Units; unsigned long Max_Speed; char Serial_Number[9]; char Manufacture_Date[11]; char Calibration_Date[11]; unsigned char Options; }</pre>	<pre>#Model Name, Type, FSD, Units, Maximum Speed, Serial Number, Manufacture Date, Calibration Date, Options; CR/LF added for readability.</pre>																

Transducer Data

Get Torque

	Binary	ASCII
Command	50	#50;
Description	Requests the current Torque value, if averaging has been enabled then this value is averaged.	
Parameters	None	
Return Value	Torque in the Transducers native units.	
	Float	#±0000000.000;

Get Peak Torque

	Binary	ASCII
Command	51	#51;
Description	Requests the current Peak Torque value.	
Parameters	None	
Return Value	Peak Torque in the Transducers native units.	
	Float	#±0000000.000;

Get Peak Torque Auto Reset

	Binary	ASCII
Command	52	#52;
Description	Requests the current Peak Torque Auto Reset value.	
Parameters	None	
Return Value	Peak Torque Auto Reset in the Transducers native units.	
	Float	#±0000000.000;

Get Peak Torque CW

	Binary	ASCII
Command	53	#53;
Description	Requests the current clockwise Peak Torque value.	
Parameters	None	
Return Value	Peak Torque value in the Transducers native units.	
	Float	#±0000000.000;

Get Peak Torque CCW

	Binary	ASCII
Command	54	#54;
Description	Requests the current counter-clockwise Peak Torque value.	
Parameters	None	
Return Value	Peak Torque value in the Transducers native units.	
	Float	#±0000000.000;

Get PeakMinMax Max

	Binary	ASCII
Command	55	#55;
Description	Requests the current Max value from the PeakMinMax data.	
Parameters	None	
Return Value	PeakMinMax Max Torque value in the transducers native units.	
	Float	#±0000000.000;

Get PeakMinMax Min

	Binary	ASCII
Command	56	#56;
Description	Requests the current Min value from the PeakMinMax data.	
Parameters	None	
Return Value	PeakMinMax Min Torque value in the transducers native units.	
	Float	#±0000000.000;

Get PeakMinMax

	Binary	ASCII
Command	57	#57;
Description	Requests the PeakMinMax data.	
Parameters	None	
Return Value	PeakMinMax data consisting of two Torque values in the transducers native units.	
	PeakMinMax structure	#Max,Min; #±0000000.000,±0000000.000;

Get Torque - Convert Units To

	Binary	ASCII
Command	60	#60, UNITS ;
Description	Requests the current Torque value and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	Torque in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get Peak Torque - Convert Units To

	Binary	ASCII
Command	61	#61, UNITS ;
Description	Requests the current Peak Torque value and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	Peak Torque value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get Peak Torque Auto Reset - Convert Units To

	Binary	ASCII
Command	62	#62, UNITS ;
Description	Requests the current Peak Torque Auto Reset value and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required. Parameter is acknowledged in ASCII mode.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	Peak Torque Auto Reset value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get Peak Torque CW - Convert Units To

	Binary	ASCII
Command	63	#63, UNITS ;
Description	Requests the current clockwise Peak Torque value and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	Peak Torque value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get Peak Torque CCW - Convert Units To

	Binary	ASCII
Command	64	#64, UNITS ;
Description	Requests the current counter-clockwise Peak Torque value and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	Peak Torque value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get PeakMinMax Max - Convert Units To

	Binary	ASCII
Command	65	#65, UNITS ;
Description	Requests the current Max value from the PeakMinMax data and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	PeakMinMax Max Torque value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get PeakMinMax Min - Convert Units To

	Binary	ASCII
Command	66	#66, UNITS ;
Description	Requests the current Min value from the PeakMinMax data and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	PeakMinMax Min Torque value in the selected unit. Parameter is acknowledged in ASCII mode.	
	Float	#ACK,±0000000.000;

Get PeakMinMax - Convert Units To

	Binary	ASCII
Command	67	#67, UNITS ;
Description	Requests the PeakMinMax data and converts the native units to the selected units.	
Parameters	UNITS - The UNITS parameter specifies the Torque unit to convert the Torque value to. Use the Unit key to find the corresponding value for the unit required.	
	Unsigned Char	UNITS value as an additional parameter.
Return Value	PeakMinMax data consisting of two Torque values in the selected unit. Parameter is acknowledged in ASCII mode.	
	PeakMinMax structure	#ACK,Max,Min; #ACK, ±0000000.000, ±0000000.000; CR/LF added for readability.

Get Speed

	Binary	ASCII
Command	100	#100;
Description	Requests the current Speed value. The slow speed capture mode is used.	
Parameters	None	
Return Value	Speed in RPM.	
	Float	#±0000000.000;

Get Power

	Binary	ASCII
Command	101	#101;
Description	Requests the current Power value in Watts. The slow speed capture mode is used.	
Parameters	None	
Return Value	Power in Watts.	
	Float	#±0000000.000;

Get Temperature Ambient

	Binary	ASCII
Command	102	#102;
Description	Requests the Transducers internal ambient Temperature.	
Parameters	None	
Return Value	Temperature in degrees C (°C).	
	Float	#±0000000.000;

Get Temperature Shaft

	Binary	ASCII
Command	103	#103;
Description	Requests the Transducers shaft Temperature.	
Parameters	None	
Return Value	Temperature in degrees C (°C).	
	Float	#±0000000.000;

Get SlowCap Speed

	Binary	ASCII
Command	110	#110;
Description	Requests the current Speed value from the slow speed capture system.	
Parameters	None	
Return Value	Speed in RPM.	
	Unsigned Int	#±0000000.000;

Get FastCap Speed

	Binary	ASCII
Command	111	#111;
Description	Requests the current Speed value from the fast speed capture system.	
Parameters	None	
Return Value	Speed in RPM.	
	Unsigned Int	±0000000.000

Get SlowCap Power in Watts

	Binary	ASCII
Command	112	#112;
Description	Requests the current Power value in Watts, using the current torque and speed value from the slow speed capture system.	
Parameters	None	
Return Value	Power in Watts.	
	Float	#±0000000.000;

Get FastCap Power in Watts

	Binary	ASCII
Command	113	#113;
Description	Requests the current Power value in Watts, using the current torque and speed value from the fast speed capture system.	
Parameters	None	
Return Value	Power in Watts.	
	Float	#±0000000.000;

Get SlowCap Power in HP

	Binary	ASCII
Command	114	#114;
Description	Requests the current Power value in Horse Power (HP), using the current torque and speed value from the slow speed capture system.	
Parameters	None	
Return Value	Power in HP.	
	Float	#±0000000.000;

Get FastCap Power in HP

	Binary	ASCII
Command	115	#115;
Description	Requests the current Power value in Horse Power (HP), using the current torque and speed value from the fast speed capture system.	
Parameters	None	
Return Value	Power in HP.	
	Float	#±0000000.000;

Transducer Control***Reset Specified Peaks***

	Binary	ASCII
Command	146	#146, <i>FLAGS</i> ;
Description	<p>Resets the stored peak values or zero's the transducer in accordance with binary flags specified as an additional parameter.</p> <p>The ASCII implementation of this command is a straight forward request with a single parameter.</p> <p>The binary implementation requires some handshaking which differs from the standard request.</p> <p>The parameter value is an Unsigned Int which is 2 bytes, because of this some handshaking is required to ensure that no overflows occur in the Transducer's internal processor.</p> <p>The procedure for transmitting the value is outlined below:</p> <ol style="list-style-type: none"> 1. Transmit the command byte (Unsigned Char) with a value of 146. 2. Receive a byte (Unsigned Char); the byte will have a value of 145, the value has no significance. 3. Transmit the 2 byte (Unsigned Int) reset request parameter, LSB first. 4. Receive a byte (Unsigned Char), this second byte acts as a confirmation, its value will be 145, again the value has no significance. 	

Parameters	<p>FLAGS - The FLAGS parameter specifies which stored values should be reset. The value is made up of binary flags, each flag signifying a value to reset.</p> <p>The input value is calculated by adding together or OR'ing the flag values. The table below shows the reset flags and there respective values.</p>	
	Flag Value	Value to be reset
	0x01	Transducer Zero
	0x02	Transducer Zero with Average
	0x04	Peak Torque
	0x08	Peak Torque Auto Reset
	0x10	Peak Torque CW
	0x20	Peak Torque CCW
	0x40	PeakMinMax
	0x80	Peak FastCap Speed
	0x100	Peak SlowCap Speed
	0x200	Peak FastCap Power
0x400	Peak SlowCap Power	
<p><i>Example:</i></p> <p>To reset all the torque values (Peak Torque: 0x04, Peak Torque Auto Reset: 0x08, Peak Torque CW: 0x10, Peak Torque CCW 0x20, PeakMinMax: 0x40), the input value would be 0x7C.</p> <p><i>Input Value:</i> 0x7C = 0x04 + 0x08 + 0x10 + 0x20 + 0x40.</p>		
Unsigned Int	<p>FLAGS value as an additional parameter.</p>	
Return Value	<p>See Description.</p>	
	#ACK;	

Reset ALL Peak Torque Values

	Binary	ASCII
Command	147	#147;
Description	Resets the entire memory bank of stored peak values related to Torque, values are reset to zero, except for the PeakMinMax values which are reset to the current Torque value.	
Parameters	None	
Return Value	None	#ACK;

Reset ALL Peak Values

	Binary	ASCII
Command	148	#148;
Description	Resets the entire memory bank of stored peak values related to Torque, Speed and Power. Values are reset to zero, except for the PeakMinMax values which are reset to the current Torque value.	
Parameters	None	
Return Value	None	#ACK;

Reset System Values

	Binary	ASCII
Command	149	#149;
Description	Resets the entire memory bank of stored peak values related to Torque, Speed and Power, then zero's the transducer using an averaged zero. All subsequent Torque values are offset by the zero value. Peak values are reset to zero, except for the PeakMinMax values which are reset to the current Torque value.	
Parameters	None	
Return Value	None	#ACK;

Peak Torque Reset

	Binary	ASCII
Command	150	#150;
Description	Resets the stored Peak Torque value to zero.	
Parameters	None	
Return Value	None	#ACK;

Peak Torque Auto Reset - Reset

	Binary	ASCII
Command	152	#152;
Description	Resets the stored Peak Torque AutoReset value to zero.	
Parameters	None	
Return Value	None	#ACK;

Zero Transducer with Average

	Binary	ASCII
Command	155	#155;
Description	Zero's the Transducer Torque value; all subsequent Torque readings will be offset by an averaged torque value. When the command is sent to the transducer, the firmware will average over the next 32 Torque samples, the averaged Torque value is then stored as the zero offset.	
Parameters	None	
Return Value	None	#ACK;

Zero Transducer

	Binary	ASCII
Command	156	#156;
Description	Zero's the Transducer Torque value; all subsequent Torque readings will be offset by the torque value present when zeroed.	
Parameters	None	
Return Value	None	#ACK;

Get PeakMinMax & Reset

	Binary	ASCII
Command	173	#173;
Description	Requests the PeakMinMax data and resets the stored values to the current Torque reading.	
Parameters	None	
Return Value	PeakMinMax data consisting of two Torque values in the transducers native units. The reset is acknowledged in ASCII mode.	
	PeakMinMax structure	#Max,Min,ACK; #±0000000.000, ±0000000.000, ACK; CR/LF added for readability.

Set Torque Filter

	Binary	ASCII
Command	180	#180, FILTER ;
Description	Enables and configures the Torque filtering system.	
Parameters	FILTER - Torque filter setting. Disables or sets the filtering sample level. Valid filter settings: 0 – OFF, 2, 4, 8, 16, 32, 64, 128, 256 (In binary format send 255 for 256).	
	Unsigned Char	FILTER value as an additional parameter.
Return Value	None	#ACK;

Get Torque Filter

	Binary	ASCII
Command	181	#181;
Description	Retrieves the current Torque filter setting.	
Parameters	None	
Return Value	Torque filter setting. The value returned indicates the filter level. If zero is received the filter is disabled. In binary format a filter level of 256 is output as 255.	
	Unsigned Char	#000;

Set Speed Filter

	Binary	ASCII
Command	182	#182, FILTER ;
Description	Enables and configures the Speed filtering system.	
Parameters	FILTER - Speed filter setting. Disables or sets the filtering sample level. Valid filter settings: 0 – OFF, 2, 4, 8, 16, 32, 64, 128, 256 (In binary format send 255 for 256).	
	Unsigned Char	FILTER value as an additional parameter.
Return Value	None	#ACK;

Get Speed Filter

	Binary	ASCII
Command	183	#183;
Description	Retrieves the current Speed filter setting.	
Parameters	None	
Return Value	Speed filter setting. The value returned indicates the filter level. If zero is received the filter is disabled. In binary format a filter level of 256 is output as 255.	
	Unsigned Char	#000;